



PRODUCT BULLETIN

Carpenter Brothers, Inc.
4555 W. Schroeder Dr.
Suite 100
Milwaukee, WI 53223
Tel: 414-354-6555
Fax: 414-354-6610

Metallurgical Sampling Ferrous

Sample Spoon & Chill Rings

Division Offices:

Eastern Division
6120 Norton Center Dr.
Muskegon, MI 49441
Tel: 231-798-8819
Fax: 231-798-1960

Western Division
2828 Anthony Lane South
Minneapolis, MN 55411
Tel: 612-788-3313
Fax: 612-788-9375

For Metallurgical sampling to produce 1 ¼" sample for all spectrometer equipment. The sample spoon is investment cast of 1020 carbon steel. Life of a sample spoon can be extended by coating in a water base Zircon coating. Zircon coating is applied on the hot spoon and dries immediately. The multi use carbon chill ring is used as a metallurgical sample mold. The durability will allow you to sample multiple times.

Sample Spoon



Carpenter Brothers part
#- 10-73003
Chill Ring



Carpenter Brothers part
#-65-2595-0001

Please contact Carpenter Brothers, Inc. for more information or pricing.